




DUAL JACKS


PROTIS 1 DUAL JACKS MODULE USER MANUAL



Plug Types:




Our Jack:




How the Jack Works


Plug Not Inserted:



Plug Inserted:



CONNECTIONS



Ground Connections

Ring and RN Connection

Tip and TN Connection

**Ground RN
w/ Jumper**

**Ground TN
w/ Jumper**

***Connections mirrored for Jack #2**